


- \* inner diameter should at least be 60 including zip tie
- \*\* measured at any angle the outer diameter should not exceed 120
- \*\*\* optimal torque is 1.0Nm, maximal torque is 1.5Nm; it is highly recommended to use a torque screw driver to prevent damaging the clamp, while also giving optimal fit of the core. This is also the torque used at the testing bench. A second grub screw is hidden under the protective cover.

Flexible Split Core Current Sensor  
 for retrofit cable installation  
 ECO Standard Shape T (ID 60)  
 IEC 61869-1, IEC 61869-10  
 BIL: 0.72 / 3 / - kV

respective product code:  
 ExxxT, lxxxT  
 historic: NxxxT

Departement R&D	Technical reference ECO Standard T	Created by Markus Hollenstein 3/5/2026	Approved by Daniel Manninger 4/16/2026
 ©2026 intellectual property of Greenwood-Power GmbH, Austria		Document type technical drawing	Document status released
		Title ECO Standard T Shape universal technical drawing	
		ABAS No. n.a.	Scale 1:1
			Sheet 1/1